

Installation Instructions for Anti-Bandit Door with Tubular Frame

- The frame must be installed plumb, Square and true as the door have been factory fitted to the required limits.
- It is advisable when building-in the frame to square the frame with the leaves in them and to ensure that the top leading edges of double doors are level.
- After squaring the frame, remove rebate with Allen Key and check that the lock moves freely into lock box.
- Bolt frame to opening using holes in frame (10mm Anchor Sleeves – 100mm long) ensure the door and frame are 100% aligned.
- Refit rebate with Allen Key and only then remove brace.

